

Installation Instructions

Part Number 4500055

R1200 RT Supplemental Mirror Adapters



Wunderlich AMERICA



1. Remove top clamp of lever perch.



2. Install Mirror adapter and tighten bolts

Repeat on opposite side if installing two.



3. Screw in the base adapter(s) supplied with the Flash mirrors and tighten with a 17mm wrench. If different mirrors are being used, attach them to the adapters instead.



4. Pull back the rubber boot of the Flash mirror to access the length adjustment nut.

Ensure that the mirrors do not contact the windshield when turning the steering. Adjust the mirrors to your liking and securely tighten all fasteners.

