

REAR HUGGER ADAPTABLE TO BMW F650GS

REF:5925



INSTRUCTIONS TO ASSEMBLE

- 1. Dismount the original chainguard.
- 2 Mount the hardware (1) supplied as the figure below shows (it is supplied adhesive foam to place in the interior of the bridle as a protection of the swing arm)
- 3. Mount the wellnuts (5) on the rear hugger.
- 4 Tight the rear hugger using the M6x15 (2) screws supplied. Adjust it through the regulation that the hardware offer.
- 5 Check them periodically, and tighten the fixations.
- 6 In case your motorcycle has other accessories, observe that it does not interfere with the hugger.

Material supplied to assemble the hugger:

POS.	DESCRIPTION	CANT. / QTT.
1	Hardware	1
2	Black M6x15 screw DIN1001	5
3	Black M6x10 screw DIN1001	1
4	M6 Nut DIN6923	2
5	Wellnuts	4
6	M6 insidenuts	2
7	Adhesive foam	1

