

Installation Instructions

Before installation, we recommend thoroughly cleaning the exhaust system particularly around the area of the three attachment screws at the rear of the muffler.

Remove the original screws with a Torx T25 wrench. Place the supplied stainless washers on the original screws and re-use them to install the guard.

Before tightening any of the screws, adjust the positioning of the guard and then gradually tighten each screw until a satisfactory positioning of the guard has been achieved, then tighten the screws to a maximum torque of 2.8 NM(2 Ft. Lbs).

The guard is positioned correctly when the gap around the circumference of the silencer is even.

Re-check the tightness of the screws after 500 KM (300 miles)

